

10' x 10' Canopy Instructions

Always use Common Sense.

It is designed for temporary use only.

Do not setup on a steep incline.

Never setup in windy, rainy or snowy conditions.

Do not let snow or rain accumulate on top, it will collapse.

Always use an anchoring system; it will fly away in windy conditions.

Keep away from all fire sources, such as grills or fire pits.



Do not put away while wet or damp, this promotes mildew & rust.

NEVER LEAVE YOUR CANOPY UNATTENDED!


10ft x 10ft / 3m x 3m

SET-UP INSTRUCTIONS

It is recommended to use two people when setting up the Goliath.



1. Standing towards your partner, grasp the corner legs and extend out to arms length while stepping back. Insure that bottom truss elbows are free and not overlapping prior to opening.



6. To secure and tighten top on frame attach the adjustable loop straps sewn to top in the center on each side around the bottom truss bar.




2. Next, grasp the lower "V" of the truss that you are facing. Lift up the shelter slightly and step back until the unit is halfway open.




7. Adjust the legs to the desired setting by pressing the release buttons and pull out lower part of leg raising canopy.

8. Use the large nail stakes to secure the feet at each leg position. To anchor the unit using the stakes and rope enclosed, tie the rope through the D-Ring on the top at each corner.



3. Place fabric top on frame. Match up the hook and loop on the corners of the cover with the hook and loop at the top of legs. Make sure the center peak of canopy fabric is centered over the peak pole.



4. Pull the frame completely out until all sliders are engaged at each corner on each leg. You will have to push up on sliders to get buttons to lock in place. You may need to move around unit pulling and opening until completely open and locked.



5. With a helper, one should go to opposite legs on one side of the canopy and extend the legs by pressing the leg release button and pulling out the lower leg. Use your foot on bottom of leg to start the extension, then use your hands. This will allow the leg to extend smoothly. Repeat this step on the other side.

TAKE DOWN INSTRUCTIONS

1. Unhook the loop straps holding top on.
2. Lower the legs by pressing leg release buttons and allowing the lower part of leg to slide into upper part.
3. Press the top release button to release the framework top at each corner. Failure to release this button may damage frame when you attempt to close.
4. Remove and fold top. Remove the top after each use and store in the pocket provided on the carry bag. Never store wet. This is recommended to prevent small rips and tears. Make sure the canopy top is dry before storing.
5. Grasp the top "V" and fold in completely. Move from side to side as necessary. Careful, Watch Your Fingers.
6. Insert the legs into carry bag first then close with zippers.

SEE REVERSE SIDE FOR CARE AND WARRANTY.